

关于LSI产品 封装的 热阻、热特性参数

目次

1.	. 目的	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	• 1
2.	. 标准	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•			•	•	•	•	•	•	•	•	•	•	•	•	• 1
3.	. 用语	及	其	定	义	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	• 1
4.	. 测量	:环	境	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•			•	•	•	•	•	•	•	•	•	•	•	•	• 2
5.	. 测量	:用	基	板	规	格	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•			•	•	•	•	•	•	•	•	•	•	•	•	• 3
6.	. 芯片	温	度	的	测	量	方	法		•				•	•	•		•									•			•		•				•	•	•				•				•			•				• 4

1. 目的

在该应用笔记中,有 ROHM 制造的 LSI 芯片的封装群的热阻和热特性参数的定义及其活用方法。

2. 标准

该应用笔记中记载的内容符合JEDEC标准(JESD 51-2A, 3, 5, 7, 9, 10)。

3. 用语及其定义

- 3.1 TA (Ambient air temperature) 周围环境温度。
- 3.2 TJ (Junction temperature) PN结的结温。
- 3.3 TT (The temperature at the top center of the outside surface of the component package) 封装上表面中心温度。
- θ JA (Theta from Junction to Ambient)
 从PN结到周围环境的热阻。从多个路径进行散热。
- 3.5 Ψ_{JT} (The thermal characterization parameter to report the difference between junction temperature and the temperature at the top center of the outside surface of the component package)
 从连接到封装上面中心的热特性参数。因为在封装上面以外也进行热传导,所以根据散热量,值会有变化。




图1. 热阻 θ JA和热特性参数 ψ JT的定义 (例: HTSOP-J8)

Absolute Maximum Ratings (Ta = 25°C)

Parameter	Symbol	Rating	Unit
Supply Voltage	V_{IN}	7	V
Junction Temperature Range	Tj	-40 to +150	°C
Storage Temperature Range	Tstg	-55 to +150	°C

Caution: Operating the IC over the absolute maximum ratings may damage the IC. The damage can either be a short circuit between pins or an open circuit between pins and the internal circuitry. Therefore, it is important to consider circuit protection measures, such as adding a fuse, in case the IC is operated over the absolute maximum ratings.

Thermal Resistance(NOTE 1)

Doromotor	Cumbal	Thermal Res	Linit	
Parameter	Symbol	1s ^(NOTE 3)	2s2p ^(NOTE 4)	Unit
HTSOP-J8				
Junction to Ambient	θ_{JA}	206.4	45.2	°C/W
Junction to Top Characterization Parameter (NOTE 2)	Ψл	21	13	°C/W

(Note 1)Based on JESD51-2A(Still-Air)
(Note 2)The thermal characterization parameter to report the difference between junction temperature and the temperature at the top center of the outside surface of the component package.

(Note 3)Using a PCB board based on JESD51-3.

Layer Number of Measurement Board	Material	Board Size
1s	FR-4	114.3mm x 76.2mm x 1.57mmt
Component trace		
Copper Pattern	Thickness	
Component mounting and trace fan-out region	70μm	

(Note 4)Using a PCB board based on JESD51-7.

Layer Number of	Matorial	Board Siz	0	Thermal v	ia ^{(NOTE}	5)
easurement Board	Material	Board Size		Pitch	D	iameter
2s2p	FR-4	114.3mm x 76.2mm	n x 1.6mmt	1.20mm	0.30mm	
Component trace Copper Pattern Thickness Component mounting and trace fan-out region 70µm		Plane		Backsid	9	
		Copper Pattern	Thickness	Copper Patter	n	Thickness
		74.2mm ² (Square)	35µm	74.2mm ² (Squar	70µm	
	ayer Number of easurement Board 2s2p Component trace Copper Pattern mponent mounting	Material Material 2s2p FR-4	Layer Number of easurement Board Material Board Size 2s2p FR-4 114.3mm x 76.2mm Component trace Plane Copper Pattern Thickness Copper Pattern mponent mounting 70 mm 74.2mm²(Square)	Layer Number of easurement Board Material Board Size 2s2p FR-4 114.3mm x 76.2mm x 1.6mmt Component trace Plane Copper Pattern Thickness Copper Pattern Thickness mponent mounting 70 mm 74.2mm²(Square) 35 mm	Layer Number of easurement Board Material Board Size Thermal very Pitch 2s2p FR-4 114.3mm x 76.2mm x 1.6mmt 1.20mm Component trace Plane Backsid Copper Pattern Thickness Copper Pattern Thickness Copper Pattern mponent mounting 70 mm 74.2mm²(Square) 35 mm 74.2mm²(Square)	August Number of passurement Board Board Size Thermal via Note

(Note 5) This through hole via connects with the top copper pattern. The placement and dimensions obey a land pattern.

图2. Datesheet记载例 (例: HTSOP-J8)

4. 测量环境 (JESD51-2A)

如图3所示,在符合JESD 51-2A (Still-Air)的环境下进行热阻测量。




图3. 热阻测量环境

表1. 热阻测量机器

测量仪器	厂家	型号	备注
热特性测量仪	Mentor Graphics	T3Ster	1
恒温器	Mentor Graphics	T3Ster	-
K型热电偶 ^(NOTE1)	坂口热电	K6010	Class1 / ФО.1mm

(NOTE1)将K型热电偶固定在封装上表面中心,测量封装上表面中心温度TT。

5. 测量用基板规格

热阻测量是在如表2、图4、图5,符合JESD51-3,5,7,9,10标准的测量用基板上所实施的。

表2. 热阻测量用基板的尺寸(PKG最长边的长度适用于PKG尺寸)

	測定基板	基板材	基板尺寸	热通	FL (NOTE1)	插件通孔 (NOTE2)
	规定圣仪		圣 极八寸	间距	直径	直径
SMD	1层基板	FR4	114.3mm x 76.2mm x 1.57mmt	-	-	_
(PKG尺寸<27mm)	4层基板	ГN4	114.3mm x 76.2mm x 1.6mmt	1.20mm	Ф0.30mm	_
BGA, THD	1层基板	ED4	114.5mm x 101.5mm x 1.6mmt	-	-	Ф0.85mm
(PKG尺寸≦40mm)	mm) 4层基板 FR4		114.5mm x 101.5mm x 1.6mmt	1.20mm	Ф0.30mm	Ф0.85mm

	基板	1层(表面)铜	箔	2层、3层(内层)铜箔	4层(里面)铜	司 箔
	圣似	铜箔种类	铜箔厚度	铜箔种类	铜箔厚度	铜箔种类	铜箔厚度
SMD	1层基板	安装Land种类	70	ı	_	-	_
(PKG尺寸<27mm)	4层基板	+引出电极用的配线	70µm	74.2mm□(正方形)	35µm	74.2mm□(正方形)	70µm
BGA, THD	1层基板	安装Land种类	70µm	ı	_	-	_
(PKG尺寸≦40mm)	4层基板	+引出电极用的配线	7 OP4III	99.5㎜□(正方形)	35µm	99.5㎜□(正方形)	70µm

(NOTE1) 热通孔:通孔是用来连接全层的铜箔。配线要按Land种类来进行。(对应带散热板的封装)

(NOTE2) 插件通孔: THD安装用的通孔、连接到第1层的铜箔。配置和尺寸要按Land种类来进行。




图4. 用于热阻测量的基板的截面结构(SMD: 带散热器型)




图5. 用于热阻测量的基板的截面结构 (THD: DIP type)

6. 芯片温度的测量方法


半导体的温度测量方法有以下两种。


- ·测量封装表面温度(接触式测量/非接触式测量)
- ·测量芯片PN结的温度(测量芯片上PN连接的温度) 各自的优点/缺点如表3所示。

表3. 不同测量方法的优缺点

ſ	测量方法	优点	缺点
	测量封装表面温度	容易测量	并不是直接测量结温 容易产生环境误差
	测量芯片PN结的温度	直接测量PN结的温度 所以精度很好	在元器件上需要热测量用的端子







测量封装表面温度 热电偶(接触式)

测量封装表面温度 恒温器(非接触式)

图6. 各种测量方法图示

测量芯片PN结的温度

通过测量封装表面温度进行半导体的温度测量时,使用热特性参数(ψ JT)进行计算。 (ψ JT是表示结温TJ和封装上表面中心温度Tr之间的温度差的热特性参数,与罗姆以往记载 θ JC 是同义词。

只要将热电偶牢固地固定在封装上面中心,就可以高精度地测量封装上面中心温度TT,可以使用这个热特性参数精确地计算PN结温度。

(但是,热特性参数根据基板的散热性能(层数、铜箔覆盖率、通孔数等)而变化,因此考虑与JEDEC环境的差异。)

 $T_J = T_T + \Psi_{JT} * P$ (T_J : 接合温度、 T_T : 封装上面中心温度、P: 消耗功率)

还可以使用热阻 (θ JA) 简单计算PN结温度。

(但是,比起热特性参数,更容易受到与JEDEC环境差异的影响。)

 $T_J = T_A + \theta_{JA} * P$ (T_J : 接合温度、 T_A : 周围环境温度、P: 消耗功率)

通过封装表面温度来确认温度限界的裕度的话、可以假设封装表面温度Tc≒TT,进行以下计算

TCMAX = TJMAX - ΨJT * P (TCMAX: 封装表面最高温度、TJMAX: 最高结温、P: 消耗功率)

从上式可以算出封装表面温度的上限TCMAX。

Notes

- 1) The information contained herein is subject to change without notice.
- Before you use our Products, please contact our sales representative and verify the latest specifications:
- 3) Although ROHM is continuously working to improve product reliability and quality, semiconductors can break down and malfunction due to various factors. Therefore, in order to prevent personal injury or fire arising from failure, please take safety measures such as complying with the derating characteristics, implementing redundant and fire prevention designs, and utilizing backups and fail-safe procedures. ROHM shall have no responsibility for any damages arising out of the use of our Poducts beyond the rating specified by ROHM.
- 4) Examples of application circuits, circuit constants and any other information contained herein are provided only to illustrate the standard usage and operations of the Products. The peripheral conditions must be taken into account when designing circuits for mass production.
- 5) The technical information specified herein is intended only to show the typical functions of and examples of application circuits for the Products. ROHM does not grant you, explicitly or implicitly, any license to use or exercise intellectual property or other rights held by ROHM or any other parties. ROHM shall have no responsibility whatsoever for any dispute arising out of the use of such technical information.
- 6) The Products specified in this document are not designed to be radiation tolerant.
- 7) For use of our Products in applications requiring a high degree of reliability (as exemplified below), please contact and consult with a ROHM representative: transportation equipment (i.e. cars, ships, trains), primary communication equipment, traffic lights, fire/crime prevention, safety equipment, medical systems, servers, solar cells, and power transmission systems.
- 8) Do not use our Products in applications requiring extremely high reliability, such as aerospace equipment, nuclear power control systems, and submarine repeaters.
- 9) ROHM shall have no responsibility for any damages or injury arising from non-compliance with the recommended usage conditions and specifications contained herein.
- 10) ROHM has used reasonable care to ensure the accuracy of the information contained in this document. However, ROHM does not warrants that such information is error-free, and ROHM shall have no responsibility for any damages arising from any inaccuracy or misprint of such information.
- 11) Please use the Products in accordance with any applicable environmental laws and regulations, such as the RoHS Directive. For more details, including RoHS compatibility, please contact a ROHM sales office. ROHM shall have no responsibility for any damages or losses resulting non-compliance with any applicable laws or regulations.
- 12) When providing our Products and technologies contained in this document to other countries, you must abide by the procedures and provisions stipulated in all applicable export laws and regulations, including without limitation the US Export Administration Regulations and the Foreign Exchange and Foreign Trade Act.
- 13) This document, in part or in whole, may not be reprinted or reproduced without prior consent of ROHM.



Thank you for your accessing to ROHM product informations.

More detail product informations and catalogs are available, please contact us.

ROHM Customer Support System

http://www.rohm.com/contact/