




TinkerKit!

## TinkerKit 2/3 Axis Accelerometer



### Overview

An **accelerometer** is a device that measures acceleration. It is very common in consumer electronics such as portable electronic devices and video game controllers to detect movement using accelerometers.

**Output:** This module outputs 0V to 5V on one of its two signal pins when its G-force is changed (e.g. is moved). The value is approximately 2.5V when there is 0G on the X or Y axis. When you connect this module to the input on an Arduino using the TinkerKit Shield, you can expect to read values between 0 to 1023 while moving the module.

**Module description:** On the back of the module you can find two signal amplifier and a green LED that signals that the module is correctly powered. The module is based on the [LIS344AL](#) by ST Microelectronics, and is a three-axis accelerometer. You can get data about the third axis (referred to as Z) by soldering a header to the thru-hole labeled "Z".

This module is a **SENSOR**. The connector is an **OUTPUT** which must be connected to one of the **INPUT** connectors on the **TinkerKit Shield**.

Datasheet: [LIS344AL](#)

## Code Example

```
/*
Double Analog input, Double analog output, serial output

Reads from two analog input pins, a T000020 Accelerometer Module connected
to I0 and I1, maps the result to a range from 0 to 255
and uses the result to set the pulsewidth modulation (PWM) on two T010111
LED Modules connected on O0 and O1.
Also prints the results to the serial monitor.

created 29 Dec. 2008
Modified 4 Sep 2010
by Tom Igoe
modified 7 dec 2010
by Davide Gomba

This example code is in the public domain.

*/

#define O0 11
#define O1 10
#define O2 9
#define O3 6
#define O4 5
#define O5 3
#define I0 A0
#define I1 A1
#define I2 A2
#define I3 A3
#define I4 A4
#define I5 A5

// These constants won't change. They're used to give names
// to the pins used:
const int analogInPin1 = I0; // Analog input pin that the Accelerometer's
first pin is attached to
const int analogInPin2 = I1; // Analog input pin that the Accelerometer's
second pin is attached to

const int analogOutPin1= O0; // Analog output pin that the LED is attached
to
const int analogOutPin2= O1; // Analog output pin that the LED is attached
to

int sensorValue1 = 0; // value read from the Accelerometer's first pin
int sensorValue2 = 0; // value read from the Accelerometer's second pin

int outputValue1 = 0; // value output to the PWM (analog out)
int outputValue2 = 0; // value output to the PWM (analog out)
```

```
void setup() {  
  // initialize serial communications at 9600 bps:  
  Serial.begin(9600);  
}  
  
void loop() {  
  // read the both analog in values:  
  sensorValue1 = analogRead(analogInPin1);  
  sensorValue2 = analogRead(analogInPin2);  
  // map it to the range of the analog out:  
  outputValue1 = map(sensorValue1, 0, 1023, 0, 255);  
  outputValue2 = map(sensorValue2, 0, 1023, 0, 255);  
  // change the analog out value:  
  analogWrite(analogOutPin1, outputValue1);  
  analogWrite(analogOutPin2, outputValue2);  
  
  // print the results to the serial monitor:  
  Serial.print("accelerometer X = " );  
  Serial.print(sensorValue1);  
  Serial.print("\t accelerometer Y = " );  
  Serial.print(sensorValue2);  
  Serial.print("\t output 1 = " );  
  Serial.print(outputValue1);  
  Serial.print("\t output 2 = " );  
  Serial.println(outputValue2);  
  
  // wait 10 milliseconds before the next loop  
  // for the analog-to-digital converter to settle  
  // after the last reading:  
  delay(10);  
}
```

# AMEYA360

Components Supply Platform

Authorized Distribution Brand :



Website :

Welcome to visit [www.ameya360.com](http://www.ameya360.com)

Contact Us :

➤ Address :

401 Building No.5, JiuGe Business Center, Lane 2301, Yishan Rd  
Minhang District, Shanghai , China

➤ Sales :

Direct     +86 (21) 6401-6692  
Email      amall@ameya360.com  
QQ         800077892  
Skype      ameyasales1 ameyasales2

➤ Customer Service :

Email      service@ameya360.com

➤ Partnership :

Tel         +86 (21) 64016692-8333  
Email      mkt@ameya360.com