

Other Information

To obtain the most recent and complete documentation for this demonstration board, please refer to the Microchip web site:

<http://www.microchip.com/graphics>

Americas

Atlanta - 678-957-9614
Boston - 774-760-0087
Chicago - 630-285-0071
Dallas - 972-818-7423
Detroit - 248-538-2250
Kokomo - 765-864-8360
Los Angeles - 949-462-9523
Phoenix - 480-792-7200
Santa Clara - 408-961-6444
Toronto - 905-673-0699

Asia/Pacific

Australia - Sydney - 61-2-9868-6733
China - Beijing - 86-10-8528-2100
China - Chengdu - 86-28-8665-5511
China - Hong Kong SAR - 852-2401-1200
China - Nanjing - 86-25-8473-2460
China - Qingdao - 86-532-8502-7355
China - Shanghai - 86-21-5407-5533
China - Shenyang - 86-24-2334-2829
China - Shenzhen - 86-755-8203-2660
China - Wuhan - 86-27-5980-5300
China - Xiamen - 86-592-2388138
China - Xian - 86-29-8833-7252
China - Zhuhai - 86-756-3210040
India - Bangalore - 91-80-4182-8400
India - New Delhi - 91-11-4160-8631
India - Pune - 91-20-2566-1512
Japan - Yokohama - 81-45-471-6166
Korea - Daegu - 82-53-744-4301
Korea - Seoul - 82-2-554-7200
Malaysia - Kuala Lumpur - 60-3-6201-9857
Malaysia - Penang - 60-4-227-8870
Philippines - Manila - 63-2-634-9065
Singapore - 65-6334-8870
Taiwan - Hsin Chu - 886-3-572-9526
Taiwan - Kaohsiung - 886-7-536-4818
Taiwan - Taipei - 886-2-2500-6610
Thailand - Bangkok - 66-2-694-1351

Europe

Austria - Weis - 43-7242-2244-39
Denmark - Copenhagen - 45-4450-2828
France - Paris - 33-1-69-53-63-20
Germany - Munich - 49-89-627-144-0
Italy - Milan - 39-0331-742611
Netherlands - Drunen - 31-416-690399
Spain - Madrid - 34-91-708-08-90
UK - Wokingham - 44-118-921-5869

01/02/08



MICROCHIP

Microchip Technology Inc. • 2355 West Chandler Blvd. • Chandler, AZ 85224-6199
www.microchip.com

The Microchip name and logo are registered trademarks of Microchip Technology Incorporated in the U.S.A. and other countries. PICtail is a trademark of Microchip Technology Incorporated in the U.S.A. and other countries. All other trademarks mentioned herein are property of their respective companies. © 2008, Microchip Technology Incorporated, Printed in the U.S.A. All Rights Reserved. 12/08

DS51790A




Graphics LCD Controller PICtail™ Plus SSD1926 Board

Features

- Graphics display controller, Solomon Systech SSD1926, supporting 4/8-bit STN, 4/8-bit CSTN, 18-bit HR-TFT and 9/12/18/24-bit TFT interfaces. A detailed data sheet can be downloaded from www.solomon-systech.com. Additional samples can be procured from www.microchipdirect.com.
- SD/MMC Card socket, connected to SSD1926 via a 4-wire SD interface
- 16 Megabit (2Mx8) serial Flash memory for additional data storage
- Display connector for interfacing with different display boards
- PICtail™ Plus Interface for connecting to Explorer 16 Development Board
- PIC32 Starter Kit Connector


Getting Started




An Explorer 16 development board (DM240001) or one of the PIC32 Starter Kits (DM320001, DM320003) is required, but only one should be used. An external 9V (AC162039) power supply can be connected through the Explorer 16 or directly to connector, J5. When a PIC32 Starter Kit is used, the setup can be powered via the USB debugger. If your USB is unable to supply enough power, the external power supply should be used. Lastly, a display board, such as the Graphics Display Truly 3.2" 240x320 Board (AC164127-5), should be connected to the display connector. Several board settings can be selected.

- Jumper, JP1, connects an interrupt signal, PEN_INT, from the Display Connector to either signal, RA14 or RA15 (open by default).
- Jumper, JP2, selects the data bus width for the SSD1926 graphics display controller. In the lower position, the data bus is 8-bit and in the upper position, it is 16-bit (8-bit by default).
- Jumper, JP3, selects the chip select line between RD1 and RD11 for the Flash memory (RD1 by default).

Board Schematic (Rev. 2, Page 1 of 2)



Board Schematic (Rev. 2, Page 2 of 2)



Getting Started (Continued)

The Graphics LCD Controller PICtail™ Plus SSD1926 Board can be used in conjunction with the Microchip Graphics Library. The Microchip Graphics Library and other firmware examples can be downloaded from <http://www.microchip.com/graphics>. The Microchip Graphics Library installer will create a **Start Menu** folder under Programs\Microchip\Graphics Library vX.XX. Please refer to the “**Getting Started**” section in the Microchip Graphics Library Help at this location to program and run demonstration projects.

The Graphics LCD Controller PICtail™ Plus SSD1926 Board has a footprint for NAND Flash memory (U2). End designers may choose to install a NAND Flash (i.e., MT29F2G08AADWP). In which case, some modifications must be done. Resistor, R15, should be removed and a zero ohm resistor, R18, should be installed to switch the chip select signal from the serial Flash to the NAND Flash. Software support for the NAND Flash and SD/MMC card is not available at initial release of hardware. Please check the current release of the Microchip Graphics Library for availability.

A different display board may also be available, please check www.microchip.com/graphics for available options. If an end designer chooses to develop a custom display board, the included schematic shows the details of signal connections. Do note that a different display may require modifications to the software provided with the Microchip Graphics Library to function properly. Also refer to the SSD1926 Data Sheet, Table 6-10, as different interface modes may require different signals mapping.

Important: It is the user's responsibility to obtain a copy of, familiarize themselves fully with, and comply with the requirements and licensing obligations applicable to third party tools, systems and/or specifications. This includes, but is not limited to, Flash-based media and FAT file systems available from SD Card Association, MultiMediaCard Association and Microsoft® Corporation.

Signal Interface for Display Connector

Pin No.	Symbol	Level	Description
A1, B1	+9V	+9.0V	Power Supply
A2, B2	GND	GND	Ground
A3, A4	+3.3V	+3.3V	Power Supply
B3, B4	+5V	+5.0V	Power Supply
A5, B5	GND	GND	Ground
A6	LEFT/X-	I/O	Touch Panel Left
B6	TOP/Y-	I/O	Touch Panel Top
A7	RIGHT/X+	I/O	Touch Panel Right
B7	BOTTOM/Y+	I/O	Touch Panel Bottom
A8	PEN_INT	I	Pen Interrupt (Touch Panel Driver)
B8	SENSE	I	5-Wire Touch Panel Sense
A9	SCK	O	PIC® Microcontroller SCK
B9	SDO	O	PIC Microcontroller SDO
A10	SDI	I	PIC Microcontroller SDI
B10	SS	O	PIC Microcontroller SS
A11	BKLHT_EN	O	Enable for Backlight Driver
B11	BKLHT_PWM	O	PWM Output for Backlight Driver
A12, B12	GND	GND	Ground
A13	SHIFT	O	Pixel Shift Signal
B13	DEN	O	Data Enable for 24-Bit Digital RGB Interface
A14	FRAME	O	Frame Pulse
B14	LINE	O	Line Pulse
A15-A26, B15-B26	LDATA0-LDATA23	O	24-Bit Data
A27	GPO (DISP_ON)	O	GPO can be Configured for Display On or as General Purpose Output
B27	GPIO0 (CS)	I/O	GPIO0 can be Used for SPI CS or as General Purpose I/O
A28	GPIO1 (SCK)	I/O	GPIO1 can be Used for SPI SCK or as General Purpose I/O
B28	GPIO2 (MOSI)	I/O	GPIO2 can be Used for SPI MOSI or as General Purpose I/O
A29	GPIO3 (MISO)	I/O	GPIO3 can be Used for SPI MISO or as General Purpose I/O
A30-A31, B29-B31	NC	—	Not Connected
A32, B32	GND	GND	Ground

AMEYA360

Components Supply Platform

Authorized Distribution Brand :



Website :

Welcome to visit www.ameya360.com

Contact Us :

➤ Address :

401 Building No.5, JiuGe Business Center, Lane 2301, Yishan Rd
Minhang District, Shanghai , China

➤ Sales :

Direct +86 (21) 6401-6692

Email amall@ameya360.com

QQ 800077892

Skype ameyasales1 ameyasales2

➤ Customer Service :

Email service@ameya360.com

➤ Partnership :

Tel +86 (21) 64016692-8333

Email mkt@ameya360.com