

<a href="#">Contact Us</a>	Worldwide: <a href="#">United States</a>	<a href="#">Login</a>	<a href="#">My Freescale</a>	<input type="text" value="Enter Part Number"/>	<input type="button" value="»"/>
<a href="#">Products</a>	<a href="#">Applications</a>	<a href="#">Technologies</a>	<a href="#">Support</a>	<a href="#">Buy</a>	<a href="#">About Freescale</a>
				<input type="text" value="Enter Keyword"/>	<input type="button" value="»"/>

[Welcome Guest](#) [Register or Login](#) [Annotate this Page](#) [Browse History](#) [Why Should I Register?](#)

Page Actions

[Freescale](#) [Power Architecture Processors](#) [Power Architecture Automotive Controllers \(5xx/5xxx\)](#) [51xx Controllers](#) [ADS512101](#)

## ADS512101: Advanced Development System for MPC5121e

[Overview](#)

[Documentation](#)

[Downloads](#)

[Buy / Specifications](#)

[Training & Support](#)


[Application Notes](#) [Buy](#)



The ADS512101 is a Mini-ITX embedded advanced development mainboard for the MPC5121e. It can be used as either an evaluation tool, development system or target product. It can be used with all standard Mini-ITX accessories. The product kit includes a 5V wallcube and worldwide adapters, pre-loaded U-Boot, quick start guide and CD with demonstration software, schematics, user manual, and 3rd party information.

### Features

The ADS5121 features: Standard Mini-ITX Mainboard, 17cm x 17cm; LVDS 24bit (LCD), XGA, HDMI video support; SATA/PATA (IDE) support; Micro-SD Card slot; PCI slot, 2 Mini-PCI (radio slots); 10/100 Ethernet copper; RS232, CAN (2 each, Dsub & RJ); DDR2 RAM; Power Save Hibernate; NOR, NAND, and Backup FLASH; Local Bus IO connector; USB A, B, OTG; JTAG and Control CPLD; Power connectors for 5V external power supply or standard ATX power supply.



### Featured Documentation

[MPC5121EAUTOFS](#): MPC5121e Automotive Fact Sheet  
[MPC5121ECONFS](#): MPC5121e Consumer and Industrial Fact Sheet  
[MPC5121EPB](#): MPC5121e Product Brief  
[FLYMP5121ECON](#): MPC5121e Advanced Development System Reference Board Fact Sheet  
[E300CORERM](#): e300 Power Architecture Core Family Reference Manual

### Increase Your Knowledge

**Design News Update**  
 Subscribe for design tips, tricks and product news delivered to your inbox.

**On-Demand Training**  
 Learn from the experts at your convenience.

[www.freescale.com](http://www.freescale.com)

[Site Map](#)

[Terms of Use](#)

[Privacy Practices](#)

[Newsletter](#)

[View Agreement](#)

[RSS Feeds](#)

© Freescale Semiconductor, Inc. 2004 - 2009. All Rights Reserved.



Feedback

# AMEYA360

Components Supply Platform

Authorized Distribution Brand :



Website :

Welcome to visit [www.ameya360.com](http://www.ameya360.com)

Contact Us :

➤ Address :

401 Building No.5, JiuGe Business Center, Lane 2301, Yishan Rd  
Minhang District, Shanghai , China

➤ Sales :

Direct     +86 (21) 6401-6692  
  
Email        amall@ameya360.com  
  
QQ            800077892  
  
Skype        ameyasales1 ameyasales2

➤ Customer Service :

Email        service@ameya360.com

➤ Partnership :

Tel            +86 (21) 64016692-8333  
  
Email        mkt@ameya360.com